

INSTRUKCJA MONTAŻU PÓŁKI NA BUTY - TIKI / NORI

Przed rozpoczęciem montażu i użytkowania, należy dokładnie zapoznać się z niniejszą instrukcją.

Ważne: Instrukcję należy zachować na przyszłość by w razie potrzeby do niej wrócić.

Ostrzeżenia:

- nie należy zezwalać dzieciom na składanie lub rozkładanie półki,
- nie zaleca się wielokrotnego składania i rozkładania półki (wielokrotne składanie i rozkładanie półki, może przyczynić się do zmniejszenia jej stabilności),
- podczas montażu należy zachować ostrożność
- elementy opakowania (w tym karton, foliowe torby itd.) nie są zabawką, należy trzymać je poza zasięgiem dzieci w przeciwnym przypadku istnieje ryzyko uduszenia lub poważnego uszczerbku na zdrowiu,
- produkt nie jest zabawką,

Użytkowanie półki:

- półkę należy używać na twardej, równej powierzchni,
- należy używać półkę wyłącznie zgodnie z jej przeznaczeniem
- produkt do użytku wyłącznie wewnątrz pomieszczeń,
- produkt do użytku domowego.

Czyszczenie i konserwacja:

Półkę należy czyścić wilgotną, miękką szmatką, następnie wytrzeć do sucha. Półkę należy chronić przed silnym zabrudzeniem. Nie należy czyścić półki za pomocą silnych detergentów ani ostrych przedmiotów.

Producent:
MIROSŁAW GOCKOWIAK,
Ciele, ul. Przylesie 3,
86-005 Białe Błota, Polska
Wyprodukowano w ChRL

MANUAL INSTRUCTION FOR SHOE RACK TIKI /NORI

Before starting the assembly and use, please read these instructions carefully.

Before installation, check whether all elements are present in the package.

Important: Keep this manual for future reference and refer to it if necessary.

warnings:

- The packaging components (including cardboard, plastic bags, etc.) are not a toy, keep them out of the reach of children, otherwise there is a risk of suffocation or serious damage to health.
- Product is not a toy, small parts can be swallowed by children causing risk of suffocation. Product should be used under the supervision of responsible adult.

Use:

The shoe rack should be use on a hard, even surface,

Shoe should only be used indoor, without exposing them to moisture or excessive UV radiation.

Regularly check that no element of the furniture has been damaged or excessively worn.

Discontinue use of the product if it is damaged

Taking care of your comfort and safety, we recommend that you use the furniture only in the way for which it was intended.

Cleaning and maintenance:

Before using a cleaner, carefully read its label to make sure it is correct for your product.

The shoe rack should be cleaned with a damp, soft cloth and then wiped dry. The shelf should be kept from heavy soiling. Do not clean the shelf with strong or abrasive detergents. Remember to remove any dirt on a regular basis, as after a long time they will become harder to remove and may even discolor the material.

Manufacturer:

MIROSŁAW GOCKOWIAK,
Ciele, ul. Przylesie 3,
86-005 Białe Błota, Poland
Made in PRC

